
# Type X

## Cavitray for Gable Abutments

- High performance approved Cavitray for abutments
- Adjusts to cavity width ensures correct relationship
- Integral anticapil features and integrity strip
- Traditional or timber frame construction
- Clear cavity compartment area unobstructed flow
- Attached shaped flashing secured in bosem jaw



#### **USE**

To provide the stepped DPC and external weathering flashing where a sloping roof abuts a masonry wall.

#### **SOLUTION**

The Type X Cavitray is a preformed DPC unit with an attached ready-shaped flashing. When laid in every course of a cavity wall external skin against which a sloping roof abuts, trays provide continuous stepped DPC protection running parallel with the slope. Water and dampness in the exposed masonry skin above this stepped arrangement is prevented from gravitating downwardly below it. Thus the masonry skin is wet above the roofline but remains dry where it becomes an internal wall.

The Type X Cavitray requires building into one skin only and does not interpose the inner leaf. Each tray has a hinged self-supporting cavity upstand that adjusts to suit the cavity width. This facilitates

compatibility with the cavity dimension as built - as opposed to the cavity dimension as intended.

The moulded features on every tray aid swift and accurate positioning. The mason is required to set up a chalk line matching the roof pitch and build one tray into every course with its corner on the line. This simplified installation procedure ensures all trays align and are correctly distanced.

The flashing on every tray is manufactured of lead. Alternatives may be selected from our range including a synthetic flashing. Each flashing is bonded onto the tray and is shaped to suit the roof pitch.

Flashings are simply dressed when the roof finish has been completed. Short flashings are attached where dressing is over a secret gutter or soaker, and long flashings are attached where dressing is directly over a suitably profiled tile.

#### **PRODUCT NAME - GROUP**

Type X for Sloping Abutments

### CAVITY WIDTHS ACCOMMODATED

50mm up to 140mm (std range)

### PITCHES ACCOMMODATED

15 degrees to 70 degrees (std range)

### DIMENSIONS

#### INTERMEDIATE SIZES

15 degrees 17.5 degrees 21 - 25 degrees 330mm x 130mm x 192mm vert 270mm x 130mm x 192mm vert 26 - 40 degrees 230mm x 130mm x 192mm vert 40 - 70 degrees 180mm x 130mm x 192mm vert

#### RIDGE TRAY SIZES

900mm x 130mm x 192mm vert 15 - 20 degrees 21 - 25 degrees 750mm x 130mm x 192mm vert 26 - 70 degrees 570mm x 130mm x 192mm vert

#### FLASHINGS

Short: 75mm min > 280mm Long: 225mm min > 330mm

All dimensions vary pending actual pitch

#### **ANGLES**

220 x 220 external 120 x 120 internal

#### **BESPOKE OPTIONS**

Yes - all heights, depths & widths

### TRADITIONAL CONSTRUCTION COMPATIBLE

TIMBER FRAME CONSTRUCTION COMPATIBLE

NEW WORK APPLICATIONS

**RETROFIT / REMEDIAL APPLICATIONS** 

#### **MASONRY SKIN STYLES**

See Multicourse for non-std sizes

#### **UNDULATING / SPLIT MASONRY FACES**

See Designers' Comments for guide


#### **CURVED WALL ON PLAN APPLICATIONS**

Yes - see Curved Wall entries CONGRUENT WITH OTHER WALL ELEMENTS

ARRESTED WATER EVACUATION

Via Caviweeps (selection) in perp joints

THERMAL TRANSMISSION OF MATERIAL Negligible





Standard brickwork courses.

#### **DESIGNERS' COMMENTS**

The original code of practice 121:101:1951 showed a cavity DPC arrangement with a 75mm upstand. We always considered this far too small an upstand in our experience for new work applications. Eventually the new code of practice revised the upstand height to 150mm, a dimension which is now prominent in BS5628. However, it is interesting to note that not all manufacturers produce to this stipulated height.








# Type X (continued)

## Cavitray for Gable Abutments



#### **CALCULATING GABLE REQUIREMENTS**

We offer to take-off and schedule your requirement and invite you to take advantage of our service. Alternatively, you may carry out your own calculations as follows:

#### Calculate each slope separately.

This slope is a left hand slope and requires left hand trays.

Calculate by counting the courses - or measuring the vertical rise and dividing by 75mm.

Allow the bottom tray to be a catchment tray or corner tray as applicable. All other trays up the slope will be intermediate trays.

A ridge tray finally caps the top of a conventional gable (one ridge tray straddles both slopes).

Then calculate the right hand slope opposite. Confirm total tray numbers required together with the following:

Outer skin type and thickness?

Cavity total width and whether any insulation present?

Are long flashings or short flashings required?


#### **SPECIFICATION WORDING**

Approved Type X Gable Abutment Cavitrays from Cavity Trays of Yeovil, Somerset BA22 8HU (01935 474769).

Type X Cavitrays to suit ..... (state pitch) pitch roof, complete with attached code 4 lead flashings to dress over .... (state tiles or state upstand of secret gutter or soaker). Standard brickwork coursing (or state otherwise). Cavity size = ..... Lay within mortar bed, one per course, up the slope. Specify total number of handed intermediate, ridge, catchment and external angles.

#### **HOW TO ORDER**

We offer a free scheduling / design service and will determine your requirements. Alternatively, calculate each slope separately by counting the courses. Allow the bottom tray to be a catchment or corner angle. All other trays will be intermediate trays until you reach the top of the slope. The top tray on a conventional full gable will be a ridge tray. An example of a typical gable is shown above and clearly indicates how the quantities and tray types are determined.



# Type X (continued)

# Cavitray for Gable Abutments

#### Ridge tray

This straddles the ridge. It has two open ends and thus allows water to discharge to the left or to the right

#### Intermediate tray

Intermediate trays are supplied handed and built into each course up the rake of the roof. Each tray has an end upstand so water can only discharge via the open end of the tray.

#### Catchment tray

This is similar to an intermediate tray but has upstands to both ends. Its function is to receive water from the intermediate trays and discharge this collected water through a Caviweep supplied with the tray.

#### Internal / External Angles


An angle is used instead of a catchment tray if the abutment ends or returns on a corner. An angle may also provide a link with horizontal trays if required.











Short lead flashing for dressing over upstand of soakers (Shown in wider part insulated cavity.)




Long lead flashing for dressing directly over roof tiles.

#### Short leads

Short flashing for dressing over the upstand of a secret gutter or soakers. Whether secret gutter or soaker, it should rise against the masonry face and terminate just under the inboard end of the tray. In this example, partial fill insulation is also present.

#### Long leads


Long flashing for dressing directly over roof tiles. This option is appropriate where the tiles are suitably shaped (not flat or minimally undulated).



# Type X (continued)

## Cavitray for Gable Abutments


- High performance approved Cavitray for abutments
- Adjusts to cavity width ensures correct relationship
- Integral anticapil features and integrity strip
- Traditional or timber frame construction
- Clear cavity compartment area unobstructed flow
- Attached shaped flashing secured in bosem jaw




Type X Cavitrays are suitable for use in both traditional and timber frame construction where the course size is 75mm (standard brickwork coursing).

If you require trays for alternative coursings or trays for masonry of greater thickness, please read the section dealing with multi-course trays. We are able to supply to all construction dimension requirements.

European Technical Approval has been awarded to Cavity Trays Ltd for the Type X Cavitray and other Cavitray systems within its range. No other UK manufacturer of trays holds this award.





#### **DESIGNERS' COMMENTS**

Type X Cavitrays have always been produced to this dimension, prior to any BS enforcement. Tests have also established that water can be forced under some damp-proof courses if constantly high pressure differentials exist. Thus the requirement for all trays to be bedded on mortar to achieve solidity of bond and to ensure winddriven rain cannot penetrate beneath same.

